

Proximity sensor - quick program -

It is advised to use the table below and number the tags. This will assist in deleting a lost tag in the future.

Action	indicator lights		
	Amber	Red	Green
Power up	Flashing	Off	Off
Present first tag	On	Flashing	Off (This is now master)
Wait 10 seconds	On	Off	Off
Present Master again	Flashing	On	On
Present user tag 1 followed by all user tags requiring programming	Flashing	On	On – Unit beeps
Wait 10 seconds	On	Off	Off

All tags are now programmed. To check - offer each tag and the unit should beep twice and the amber and green lights stay on whilst the output is active.

<i>Tag</i>	<i>User</i>	<i>Tag</i>	<i>User</i>
1		10	
2		11	
3		12	
4		13	
5		14	
6		15	
7		16	
8		17	
9		18	

If you require more advanced functions or latched outputs, please see the full instructions.